

INSTRUCTION SHEET

572210/57221F/572220/57222F/572221F

UPHOLSTERED BED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and or screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

Assembly Procedure: (Please follow the sketches below.)

Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.

Step 1: Screw the Upper part of leg(C) to the Headboard (F) and then through the Center part of leg (A) screw the Bottom part of leg (D) to Upper part of leg(C).

Step 2: Install the Bedrail leg (I) to the Side rail (G) with Flat washer (8), spring washer (2) and Phillip head bolt (7) using Wrench (6).

Step 3: Screw the Upper part of leg(C) to the Footboard (H) and then through the Footboard stretch (E) screw the Bottom part of leg (D) to Upper part of leg (C).

Step 4: Assemble the Side rail (G) to the Headboard (F) and Footboard (H) with Bolt (1), Curved washer (3), spring washer (2) and Nut (4). Tighten them by Wrench (6).











Step 5: Screw the Slat center support (B) to the Slat Panel (J) by hand.

Step 6: Screw (5) the Slat panel (J) to the side rail (G) using screwdriver (not provided).









Note: 572210/57221F has 3pcs Center Supports

Assembly is now complete.

PARTS LIST

A	Center part of leg		2PCS
B	Slat center support		6PCS
C	Upper part of leg		5PCS
D	Bottom part of leg		5PCS
E	Footboard Stretch		1PC
F	Headboard		1PC
G	Side Rail		2PCS
H	Footboard		1PC
I	Bedrail leg		2PCS
J	Slat Panel		3PCS

HARDWARE PACK (F)

1	BOLT	 5/16" * 3"	8PCS
2	SPRING WASHER	 5/16"	12PCS
3	CURVED WASHER	 27.5*8*15mm	8PCS
4	NUT	 13*13*5mm	8PCS
5	SCREW	 8*1-1/4"mm	6PCS
6	WRENCH	 87*12mm	1PC
7	PHILLIP HEAD BOLT	 5/16" * 1-3/4"	4PCS
8	FLAT WASHER	 5/16" * 16 * 1.2mm	4PCS

INSTRUCTION SHEET

572210/57221F/572220/57222F/572221F

UPHOLSTERED BED

