

## GENERAL INSTRUCTION SHEET

414

Footboard

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

**Caution:** (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and or screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

### PARTS LIST:




#	Description	Qty.	#	Description	Qty.
A	Footboard	1pc	B	foot	2pcs
C	Hardware pack	1bag			


**Assembly Procedure:** (Please follow the sketches below.)

**Step 1:** Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.

**Step 2:** Put the footboard (A) upright down on a soft and smooth surface to avoid damage or being scratched. Insert wood dowels (3) into predrilled holes into the footboard (A). Attach the foot (B) to the footboard with allen head bolt (1) using allen wrench(2) from hardware pack (C)

**Assembly is now complete.**

HARDWARE LIST(C)			Q'TY
1	ALLEN HEAD BOLT	 5/16"*4"	2 PCS
2	ALLEN WRENCH	 70*50*5MM	1 PC
3	WOOD DOWEL	 7*40MM	2 PCS



Step 2