

INSTRUCTION SHEET

ASSEMBLY INSTRUCTIONS

U470310H	Sable Bed Headboard Queen
U470310F	Sable Bed Footboard Queen
U470310R	Sable Bed Rails Queen
U470A310H	Desert Bed Headboard Queen
U470A310F	Desert Bed Footboard Queen
U470A310R	Desert Bed Rails Queen

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipping.






Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on a damp cloth. The cloth should not be excessively wet. Polish finish with a soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.







(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and (or) screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

Parts List:

Description	Sketch	QTY
Headboard (A)		1 pc
Footboard (B)		1 pc
Side Rail (C)		2 pcs
Support Leg (D)		5 pcs
Slat (E)		5 pcs

Side Rail Hardware List:

1	Threaded bolt	5/16"x3"		8 pcs
2	Curved washer	5/16"		8 pcs
3	Spring washer	5/16"		8 pcs
4	Nut	5/16"		8 pcs
5	Wrench	12mm		1 pc
6	Screw	#8x1-1/4"		10 pcs

Assembly Procedure: (Please follow the sketches below.)

Step 1: Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.

Step 2: Assemble Side rails (C) to Headboard (A) and Footboard (B) using Threaded bolt (1), Curved washer (2), Spring washer (3), Nut (4). Tighten all nuts securely with Wrench (5), but do not over tighten.

Step 3: Assemble Support legs (D) into Slats (E).

Step 4: Attach Slats (E) on the Side rails (C) using Screws (6) as shown. Adjust the height of Support legs (D) by turning adjustable levelers located on the bottom of Support legs (D), clockwise to lower and counterclockwise to raise.

Assembly is now complete.

INSTRUCTION SHEET**ASSEMBLY INSTRUCTIONS**

U470310H	Sable Bed Headboard Queen
U470310F	Sable Bed Footboard Queen
U470310R	Sable Bed Rails Queen
U470A310H	Desert Bed Headboard Queen
U470A310F	Desert Bed Footboard Queen
U470A310R	Desert Bed Rails Queen

