



15017A - TEAK ROUND DINING TABLE 54 INCH

PART LIST:

A. TOP TABLE FRAME 1PCE



B. LEGS 4 PCS



HARDWARE :

C. FLAT WASHER 8 PCS


D. SPRING WASHER 8 PCS

E. NUT 8 PCS


F. WRENCH 1PCE

G. WOODEN PLUG 1PCE


H. WOODEN REDUCER 1PCE




1



2



3



4

