








ASSEMBLY INSTRUCTIONS


SIESTA DINING SIDE CHAIR

COMPONENT LIST

1		TOP	1
2		BASE	1
3		SEAT CUSHION	1

HARDWARE LIST


A		HEX KEY L4	1
B		JCBC BOLT M6 X 80MM SS	7
C		FLAT WASHER M6 X Ø18MM SS	7
D		SPRING WASHER M6 X Ø11MM SS	7



STEP 1


REMOVE ALL LOWER BARS BY OPENING THE BOLTS COUNTERWISE

ASSEMBLY INSTRUCTIONS SIESTA DINING SIDE CHAIR




ATTACH THE TOP AND BASE USING BOLTS,
SPRING WASHER, AND FLAT WASHER

STEP 2




STEP 3

PLACE THE CUSHION ON THE TOP



STEP 4

ATTACH THE CUSHION AND TOP USING BOLTS
FROM THE HOLES UNDER THE BASE



FINISH