

INSTRUCTION SHEET

932/994/995/996-180

The Lady's Dresser

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and/or screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

PARTS LIST:

#	Description	Qty.	#	Description	Qty.
A	Case	1 pc	B	Rear Door	1 pc
C	Front Door	1 pc	D	Foot	4 pcs

Assembly Procedure: (Please follow the sketches below.)

Step 1: Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.

Step 2: Screw the feet (D) into the bottom of case (A) as shown.

Step 3: Remove the second row of drawers from the case (A) as shown.

Step 4: Note: The rear door (B) is the left side facing door and must be attached to the inner track

groove. The rear door (B) must be installed first. To install the doors, first locate the two locking pins (located on the door back) and push the toggle switches downward into the "unlocked" position.

Position the door's bottom rollers on the bottom track groove of the case. While holding the bottom rollers in place, position the toggle pins in the top track and push in the toggle pins to the "locking" position. Repeat for the second door. Once the doors are secured to the case, they will slide to the left and right to open and close position.


Door alignment and track sliding can be changed by adjusting either one or both rollers at the bottom of the doors. The bottom drawers must be removed to adjust the doors when installed in the case.

Follow the diagram by using a Phillips head screwdriver to turn the adjust screw on the back of the door. This will either raise or lower the roller. Only very minimal roller adjustments should be needed to correct any alignment issues.


Step 5: Re-install the drawers from step 3.

Assembly is now complete.



Step 2



Step 3



Step 3



Step 3

