

Note: Removal of sliding doors should follow either of these two methods:

1. Slide the doors into a fit position; push in the buttons at the back top of the door and remove.
2. Slide the doors into a fit position; adjust the height of the door guide caster at the back bottom of the door fully to the 'DOWN' position as shown with a Phillips head screwdriver then remove the door.

Installation of sliding doors should follow this method:

Install the bottom of the door into the inside slot path of the china hutch first. Push down the door lock button on the back of the door at the top, then position the door into the china hutch until it aligns with the inside slot path of the top rail. Once in place and in a fit position, push in the door lock button to secure.

The assembly is now complete.

