

INSTRUCTION SHEET

507964

Stacking Media Console

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and or screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

PARTS LIST:

#	Description	Qty.	#	Description	Qty.
A	Console	1pc	B	Foot	6pcs
C	Center support leg	1pc	D	Leg Hardware pack	1bag
E	Hardware pack	1bag			

Assembly Procedure: (Please follow the sketches below.)





Step 1: Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.




Step 2: Attach the feet (B) to the console (A) with allen head bolt (1), spring washer (2) and flat washer (3) using allen wrench (4) from leg hardware pack (D).

Step 3: Disregard this step when the upper console is not in use. Put the square foam pads (7) onto the lower console as below shown. Then attach the upper console (without feet) to the lower console and lock it with mending plate (5) and screws (6) from backside.

Note: It is best two or more persons are involved.

Assembly is now complete.

HARDWARE LIST (D)			Q'TY
1	ALLEN HEAD BOLT	 5/16"*2-1/2"	12PCS
2	SPRING WASHER	 5/16"	12PCS
3	FLAT WASHER	 5/16"*23*2mm	12PCS
4	ALLEN WRENCH	 70*30*5mm	1PC

HARDWARE LIST (E)			Q'TY
5	MENDING PLATE	 76*18*2mm	2PCS
6	SCREW	 #5*3/4"	8PCS
7	SQUARE FORM PAD	 80*20*5mm	4PCS

INSTRUCTION SHEET

507964

Stacking Media Console

