

UNIVERSAL[®]

FURNITURE

Assembly Instruction

Model #: 988628-RTA Woven Dining Chair

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Caution:

- (1) This product can best be assembled with the assistance of one person in order to prevent personal injury and to ensure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on damp cloth. Cloth should not be excessively wet. Polish finish with soft cloth and an industry recognized furniture polish.
- (2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.
- (3) Unpack and dispose of all packing material but be careful not to throw away assembled parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and or screwdrivers to prevent injury and scratching or damaging flooring.
- (4) During normal every day, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

Dining Chair Assembly Procedures:

NOTE: A Philips head screwdriver is required.

Step 1: Lay out all parts and hardware. Make sure the quantity of each is correct. Please refer to the hardware list below.

Step 2: As shown in Figure 1, attach front assembly to left & right side assembly by inserting m8 x 90 bolt (B) with lock washer (E) and flat washer (D) and tighten up using the open wrench (G). Next, insert woodscrew (F) into the pre-bored hole and tighten using a Philips head screwdriver.








Step 3: As shown in Figure 2, attach back assembly to assembled component from step 2, by inserting m8 x 100 bolt (A) with lock washer (E) and flat washer (D) into the rear corner block on both left and right side and tighten using the open wrench (G) Next, insert woodscrew (F) into the pre-bored hole and tighten using Philips head screwdriver.




Step 4: Insert m8 x 65 bolt (C) with lock washer (E) and flat washer (D) into the pre-bored hole at rear end of side assembly as shown in Figure 1, and tighten using the open wrench (G).



Step 5: Attach seat cushion, by turning the chair upside down and inserting wood screw (F) into the pre-bored Hole and tighten using a Philips head screwdriver.

Step 6: Level the chair following the "Chair leveling Instruction". This is an additional assembly instruction sheet found inside the carton.

Assembly is now complete.

HARDWARE LIST			
	DESIGN	DESCRIPTION	QTY.
A		M8 X 100 BOLT	4
B		M8 X 90 BOLT	4
C		M8 X 65 BOLT	2
D		FLAT WASHER	10
E		LOCK WASHER	10
F		WOODSCREW 1 1/2"	12
G		OPEN WRENCH	1

PARTS LIST			
	DESIGN	DESCRIPTION	QTY
A		BACK ASSEMBLY	1
B		RIGHT SIDE ASSEMBY	1
C		LEFT SIDE ASSEMBLY	1

PARTS LIST			
	DESIGN	DESCRIPTION	QTY
D		FRONT ASSEMBLY	1
E		SEAT CUSHION	1

